































	A	1pc		J	1pc
	B	1pc		L	2pcs
	C	1pc		M	1pc
	D	1pc		N	4pcs
	E	1pc		O	4pcs
	F	1pc		Q	1pc
	G	1pc		R	1pc
	H	2pcs		S	2pcs
	I	1pc		T	1pc
				U	1pc
				W	1pc
				X	3pcs
				Y	1pc

Contents:


	Z	1pc		5*60	16pcs
	AA	1pc		4*50	36pcs
	BB	2pcs		3*30	14pcs
	CC	1pc		3*25	14pcs
	DD	1pc			
		20pcs			

Assembly instructions:


Step 1



Step 2




Step 3




Assembly instructions:


Step 4



Step 5



Step 6



Step 7

